

Suction		Retarder		Ashlar		Screed	
Shelling off		Plasterer's oval		Gig stick		Trammel	
Wall plate		Setting coat		Reverse rule method		PVC (Polyvinyl Chloride)	
Dubbing out coat		PVA (Polyvinyl Acetate)		Datum		Aggregate	
Adhesion		Scrim		EML (Expanded metal Lathing)		Squeeze	
Arris		Grinning		Crazing		Peg mould	